

GAMMAPAC 38



Learn more



COMPOSITIONS :

- **High-Density Particleboard** (680 kg/m³, E1/E2 class)
- Hot-bonded edge banding applied to the sides of the particleboard panel
- 4/10 mm **galvanized Z100** steel tray (indoor use)

OPTIONS :

- Varnished top surface
- 4/10 mm galvanized Z100 steel top sheet
- Laminate, vinyl, linoleum, textile, or rubber covering

ACCORDING TO THE STANDARDS FOR RAISED FLOORS - EN 12825

DESTINATION :

- Multipurpose panel with or without a coating, designed for use in office or technical spaces. Suitable for covering with loose-lay flooring (such as carpet tiles or PVC installed with tackifier) or with factory-bonded coverings.

Dimensions	
Width 600 mm	Tolerance +/- 0,25 mm
Length 600 mm	Tolerance +/- 0,25 mm
Thickness 38 mm	Tolerance +/- 0,3 mm

TECHNICAL PERFORMANCE OF THE SYSTEM

Allowable Loads	Self-supporting Installation : 2A Point Load : 377 daN – Distributed Load : 1 885 daN/m²	Installation with 30/15 crossbars : 4A Point Load : 489 daN – Distributed Load : 2 445 daN/m²
		Installation with 40/15 crossbars : 5A Point Load : 512 daN – Distributed Load : 2 560 daN/m²
Fire Resistance	FIRE REACTION : Bfl-s1 (M1) on the underside – plenum side	
Electrostatic Property	ANTISTATIC : TRANSVERSAL ELECTRICAL RESISTANCE > 10⁹ Ohms (< 10 ⁸ OHMS WITH CONDUCTIVE COVERING)	
Acoustic Property	With laminate : 46 dBA	

ENVIRONMENTAL APPROACH

Raw finish : A	with varnish or steel sheet on upper face: A+	A ou A+ depending on the coating	FDES : INIES N°1-170:204(R1)
-----------------------	--	---	-------------------------------------

USAGE AND MAINTENANCE

	DISASSEMBLY OF THE PANELS	REASSEMBLY OF THE PANELS
Accès au plénum	Use the lifting tools designed for this purpose (suction cup). Never use a screwdriver or lever. Removal of checkerboard panels is recommended. Marking of edge panels is necessary..	Check the proper alignment of the head joints and remove any foreign objects from the jacks and crossbars. Carefully replace the panels in the same order and orientation as during disassembly
Entretien	Water or liquids can cause swelling of the panel components, oxidation, or delamination (for factory-coated panels). Excess water must be avoided. It is essential to consult the maintenance sheet (from the manufacturer) for the adhesive coating on the panel before any intervention	
Condition de stockage	The material must be stored in dry, closed premises with an ambient temperature between +12°C and +24°C and a relative humidity between 45% and 70% . It is essential not to film the pallets to avoid any condensation that could irreversibly damage the material	
Implementation	The installation rules and their conditions are defined by DTU 57-1 (P1 and P2).	

création graphique : tratdunion-com.fr